

CMS1202R SERVICE PARTS

This parts lists shows the service parts for the CMS1202R Remote.

Check the model number of the machine to be certain of obtaining the correct part.

Included at the back of the parts list are the wiring diagrams.

Table of Contents

Cabinet	Page 2
Refrigeration System	Page 3
Remote Condenser	Page 4
Control Box	Page 6
BH900 Bin	Page 7
Wiring Diagrams	Page 8


CMS1202R SERVICE PARTS

208-230/60/3

Remote Air Cooled

A35441-003


THIS UNIT MUST BE GROUNDED
USE COPPER CONDUCTORS ONLY



CMS1202R SERVICE PARTS

208-230/60/3

Remote Air Cooled



CMS1202R SERVICE PARTS

208-230/60/1


Remote Air Cooled

NOTE:
 ▲ DASHED LINES INDICATE FIELD WIRING WHICH MUST BE
 INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL
 CODE AND ALL STATE AND LOCAL CODES.

THIS UNIT SHOWN IN THE TIMED PORTION
 OF THE FREEZING CYCLE

THIS UNIT MUST BE GROUNDED
 USE COPPER CONDUCTORS ONLY

LINE VOLTAGE 208/230/60/1
 SEE NAMEPLATE FOR
 MAX. FUSE SIZE
 SEE NOTE ▲



CAUTION:
 MORE THAN ONE DISCONNECT MEANS
 MAY BE REQUIRED TO DISCONNECT
 ALL POWER TO THIS UNIT.

CMS1202R SERVICE PARTS

208-230/60/1

Remote Air Cooled

